

# CZ

DOSTUPNÉ FUNKCE		PŘÍKAZY AKTIVUJÍCÍ FUNKCI
AMAZON ALEXA	Zapnutí automatického úklidu	„Alexa, <b>turn on</b> <název>!“ „Alexa, <b>start cleaning</b> on <název>!“
	Vypnutí automatického úklidu	„Alexa, <b>turn off</b> <název>!“
	Sdělí % nabití akumulátoru	„Alexa, <b>what’s battery in</b> <název>?“ „Alexa, <b>what’s battery status</b> of <název>?“
GOOGLE ASSISTANT	Zapnutí automatického úklidu	„Ok Google, <b>start</b> <název>!“ „Ok Google, <b>start cleaning</b> on <název>!“
	Vypnutí automatického úklidu	„Ok Google, <b>stop</b> <název>!“ „Ok Google, <b>stop cleaning</b> on <název>!“
	Najde robota v prostoru (zvuk)	„Ok Google, <b>find</b> <název>!“ „Ok Google, <b>locate</b> <název>!“
	Sdělí % nabití akumulátoru	„Ok Google, <b>what’s my battery in</b> <název>?“ „Ok Google, <b>what’s battery status</b> of <název>?“
	Pauza	„Ok Google, <b>pause</b> <název>!“

AURUM (ETA5241)

# ENG

		AVAILABLE FUNCTIONS	COMMANDS ACTIVATING THE FUNCTION
AURUM (ETA524f)	AMAZON ALEXA	Switching on automatic cleaning	„Alexa, <b>turn on</b> <robot name>!“ „Alexa, <b>start cleaning</b> on <robot name>!“
		Switching off automatic cleaning	„Alexa, <b>turn off</b> <robot name>!“
		Reports % battery charge	„Alexa, <b>what’s battery in</b> <robot name>?“ „Alexa, <b>what’s battery status</b> of <robot name>?“
	GOOGLE ASSISTANT	Switching on automatic cleaning	„Ok Google, <b>start</b> <robot name>!“ „Ok Google, <b>start cleaning</b> on <robot name>!“
		Switching off automatic cleaning	„Ok Google, <b>stop</b> <robot name>!“ „Ok Google, <b>stop cleaning</b> on <robot name>!“
		Finds the robot in the area (sound)	„Ok Google, <b>find</b> <robot name>!“ „Ok Google, <b>locate</b> <robot name>!“
Reports % battery charge		„Ok Google, <b>what’s my battery in</b> <robot name>!“ „Ok Google, <b>what’s battery status</b> of <robot name>!“	
Pause		„Ok Google, <b>pause</b> <robot name>!“	