

CZ

DOSTUPNÉ FUNKCE		PŘÍKAZY AKTIVUJÍCÍ FUNKCI
AMAZON ALEXA	Zapnutí automatického úklidu	„Alexa, turn on <název>!“
	Vypnutí automatického úklidu	„Alexa, turn off <název>!“
	Pauza	„Alexa, pause <název>!“
	Obnovení úklidu	„Alexa, resume <název>!“
	Sdělí % nabíjení akumulátoru	„Alexa, what’s battery in <název>?“ „Alexa, what’s battery status of <název>?“
GOOGLE ASSISTANT	Zapnutí automatického úklidu	„Ok Google, start <název>!“ „Ok Google, start cleaning on <název>!“
	Vypnutí automatického úklidu	„Ok Google, stop <název>!“ „Ok Google, stop cleaning on <název>!“
	Najde robota v prostoru (zvuk)	„Ok Google, find <název>!“ „Ok Google, locate <název>!“
	Sdělí % nabíjení akumulátoru	„Ok Google, what’s my battery in <název>?“ „Ok Google, what’s battery status of <název>?“
	Pauza	„Ok Google, pause <název>!“

ENG

		AVAILABLE FUNCTIONS	COMMANDS ACTIVATING THE FUNCTION
AJRUM PRO (ETA6241)	AMAZON ALEXA	Switching on automatic cleaning	„Alexa, turn on <robot name>!“
		Switching off automatic cleaning	„Alexa, turn off <robot name>!“
		Pause	„Alexa, pause <robot name>!“
		Resume	„Alexa, resume <robot name>!“
		Reports % battery charge	„Alexa, what’s battery in <robot name>?“ „Alexa, what’s battery status of <robot name>?“
	GOOGLE ASSISTANT	Switching on automatic cleaning	„Ok Google, start <robot name>!“ „Ok Google, start cleaning on <robot name>!“
		Switching off automatic cleaning	„Ok Google, stop <robot name>!“ „Ok Google, stop cleaning on <robot name>!“
		Finds the robot in the area (sound)	„Ok Google, find <robot name>!“ „Ok Google, locate <robot name>!“
		Reports % battery charge	„Ok Google, what’s my battery in <robot name>!“ „Ok Google, what’s battery status of <robot name>!“
		Pause	„Ok Google, pause <robot name>!“